

A Weather Reach Signal Provider (WRSP) broadcasts a wireless weather signal used by ET Managers to automatically control the frequency of watering. The information on this sheet, provided by the WRSP, contains essential settings that need to be programmed in the ET Manager for proper operation:

Signal Provider Code - The code consists of 10 numbers labeled A through J. The code is unique to each WRSP.

Weather Region - The Weather Region number represents a weather station managed by the Weather Reach Signal Provider. Choose a weather region that corresponds to the weather station closest to the location of the ET Manager.

Elevation - The ET Manager uses elevation to calculate ET. The weather station elevation is provided as a reference. ET Manager location elevation must be programmed to calculate ET.

Historical ET - The ET Manager uses average daily ET for each month only as a back up to real-time ET. The Average Daily Historical ET values are provided as a reference.

Weather Reach Signal Provider Information Weatherain

Contact: Mike Holka
Email: weatherain@comcast.net
Website: www.weatherain.com
Phone: 1-(877)-44-WEATHER
Address: 1815 S. Milford Rd.
Highland, MI 48357

| Signal Provider Code | | |
|----------------------|--------|--------|
| A: 64 | D: 95 | G: 25 |
| B: 255 | E: 11 | H: 10 |
| C: 89 | F: 219 | I: 191 |
| | | J: 161 |

Weatherain, LLC provides Weather Reach Signal Service on an annual subscription basis. The first year of service and activation fee are free if Weatherain, LLC sells and installs the ET Manager for you. Please contact Weatherain, LLC for discounted subscription fees if you are an irrigation contractor or have multiple properties. After programming the Weatherain Signal Provider code, complete the Weather Signal test as described in the Installation Guide. The Attention light will be on and the Attention Message on the display will read " No Signal Service". Activate the ET Manager by calling us and providing billing information and serial number of your product or by going to our website, www.weatherain.com, and activating in our online store. Once you have subscribed either by phone or online we will send a command to activate your ET Manager. The "No Signal Service" Attention Message will disappear and your activation is completed. Thank you for your business.

Weather Regions

Weather Region 10 – Oakland West

Location: 1815 S. Milford Rd.
City: Highland, Michigan
Elevation: 1020 Feet

| Average Daily Historical ET | | |
|-----------------------------|------------|------------|
| Jan: 0.02" | May: 0.13" | Sep: 0.10" |
| Feb: 0.03" | Jun: 0.16" | Oct: 0.06" |
| Mar: 0.05" | Jul: 0.16" | Nov: 0.04" |
| Apr: 0.09" | Aug: 0.13" | Dec: 0.02" |



Because of the nature of radio transmission, strength of signal varies depending upon location.